



NOTES:

1. ALWAYS PUT A BEND OR "GOOSENECK" IN THE SERVICE LINE PRIOR TO CONNECTING TO PROVIDE FLEXIBILITY AND "GIVE" TO COUNTER THE EFFECT OF A LOAD DUE TO SETTLEMENT OR EXPANSION AND/OR CONTRACTION.
2. 1" AND 2" C.C. THREAD.



**DEPARTMENT OF PUBLIC WORKS
ENGINEERING DIVISION
TOWN OF BILLERICA,
MASSACHUSETTS**

**WATER SERVICE
CORPORATION**

CREATED BY: DCW/KCS

SCALE: NTS

FILE:

CHECKED BY: GA/JT

DATE: 06/29/2015